




Tamaños Botones



Línea:	10	12	14	16	18	20	22	24	26	28	30	32	34	36	40	44	48	50	54	60	65	85	110
Milímetros:	6,5	7,5	9	10	11,5	13	14	15	17	18	19,5	20,5	21,5	23	25	28	30,5	32	34	37	41	52	71

